

COMPANION

OWNERS MANUAL

MEGA-JET OUTDOOR POWER COOKER

Part No. SGB04



Distributed in
New Zealand
by Gladiator Sports Ltd

Some assembly required

AUSTRALIA'S ORIGINAL OUTDOOR BRAND

IMPORTANT: Read these instructions for use carefully. Familiarise yourself with the appliance before connecting it to a gas container. Keep these instructions for future reference.

GENERAL WARNINGS

- This appliance shall only be connected to a cylinder with a POL gas cylinder valve certified to AS2469 standards.
- This appliance is designed for outdoor use only and must be operated away from any flammable material or surfaces and materials.
- This appliance is to be stored in a dry and well ventilated location free from direct sunlight.
- Do not store when valve is still connected to the cylinder.
- Make sure that the cylinder is disconnected and is stored in a well ventilated area, free from direct sunlight, heat and ignition sources.
- If being stored indoors, ensure that the location complies with the standard AS/NZS1596.
- This appliance must only be serviced by an authorised service agent, return to your place of purchase for service and repair.

DANGER!

- During operation all surfaces will be extremely hot and should not be touched or handled.
- Do not use the appliance if it is leaking, damaged or does not operate properly.
- Handle with care even after brief use, always pick up using the legs not the cylinder.
- It may be hazardous to attempt to fit other types of gas containers or cartridges.
- Use only in well ventilated areas.
- Always operate appliance a minimum of 800mm from flammable materials, walls and ceiling.
- Do not use adaptors. Do not modify appliance to fit other connectors or cylinders.
- Only use the hose assembly as supplied with this appliance for connection to the cylinder.
- Maximum length 1200mm.
- Avoid twisting or kinking the flexible hose.
- Do not use multiple appliances to heat a single utensil.
- Children must be supervised by an adult at all times.
- Never leave appliance unattended when operating.
- Use as a cooking appliance only, not to be used as heater or modified for any other reason.
- Avoid boil over and spills on to burners.



CARBON MONOXIDE HAZARD

Using this appliance in an enclosed space may cause DEATH.
Do not use in caravans, tents, marine craft, cars, mobile homes or similar locations.

IMPORTANT

- Use outdoors only.
- Keep children away at all times.
- CAUTION: Accessible parts may be very hot. Please take care when handling or moving the appliance.
- Appliance is to be used on a stable, level, flat, non-flammable surface. The appliance should be protected from direct drafts and in a well ventilated place.
- Only cooking vessels with a minimum diameter of 250mm and a maximum of 300mm are to be used with this appliance.
- Take care that the primary air intakes, located on the burner tube of this appliance are not obstructed, or that air flow is restricted by placing items or other appliances close to or adjacent to the inlets.
- If you smell gas, immediately turn the gas off at the cylinder and move the appliance and cylinder to a well ventilated area outside, keeping well away from sources of heat such as naked flames and pilot lights.
- Do not attempt to move or relocate the appliance when it is operating, extinguish the burner and allow to cool, disengage the gas cylinder then move the appliance.

CHECKING FOR GAS LEAKS



- Check that all connections are tight and that the gas cylinder connection has been tightened before you turn the cylinder gas valve on.
- **NEVER** check for leaks with a flame or pilot light.
- Using Companion Gas Leak Detection Spray or soapy water, coat all connections, if bubbles appear turn the cylinder gas control off and retighten the connection before re-testing.
- Inspect the appliance regularly for signs of wear, leaks or incorrect operation. If symptoms such as flaring of the burner, issues with lighting, damages to hoses or connections or leaks from seals or gas controls are identified do not attempt to repair, return to your authorised stockist for service and maintenance.



COMP10256



SAFETY INSTRUCTIONS

This appliance shall only be used in an above ground open air situation with natural ventilation, without stagnant areas, where gas leakage and products of combustion are rapidly dispersed by wind and natural convection.





Any enclosure in which the appliance is used shall comply with one of the following:

(A) An enclosure with walls on all sides, but with no overhead cover.



(B) Within a partial enclosure that includes an overhead cover and no more than two walls.





(C) Within a partial enclosure that includes an overhead cover and more than two walls, the following shall apply:



(1) At least 25% of the total wall area is completely open.

(2) 30% or more in total of the remaining wall side, back and front wall areas is open and unrestricted.

(3) In the case of balconies, 20% or more of the total wall area shall remain open and unrestricted.



2



2

OWNERS MANUAL

UNDERSTANDING YOUR APPLIANCE




CYLINDER CONNECTION



REGULATOR & HOSE ASSEMBLY



BURNER ASSEMBLY




TOOLS REQUIRED

- Spanner or Wrench
- Phillips Head Screw Driver



COMPONENTS



ASSEMBLY

Review the contents of the package. Make sure all listed components are included.

- Step 1.** Remove appliance from packaging and dispose of carefully.
- Step 2.** Attach legs to frame using the supplied screws, washers and locking nuts.
- Step 3.** Install burner assembly to frame with supplied nut – ensure that the heat diffuser plate is included.
- Step 4.** Align the male end fitting on the Gas Control Assembly to the venturi tube on the burner and screw in the internal thread on the burner.

Take care not to overtighten as this will strip the thread in the burner tube.

Note: Once connected, the gas control does not need to be removed for storage or when packed away.



CONNECTION

Your cooker is designed to connect directly to a gas cylinder with a POL connector using the specially designed LP Gas hose and regulator.

- Step 1.** Check that the cylinder gas control is in the “OFF” position (turned fully clockwise).
- Step 2.** Take the hose and attach to the gas inlet on the appliance, tighten up using a spanner. **DO NOT** use fingers to tighten connection.
- Step 3.** Attach the other end of the hose with the regulator to the gas cylinder, tightening using the two finger support posts.
- Step 4.** Check that gas control on cooker is turned “OFF”, then turn the cylinder gas valve on in an anti-clockwise direction for one full turn and then check the connections for leaks. If a leak is detected turn the cylinder gas valve “OFF” and retighten all connections then retest.



COMP10256



LIGHTING THE COOKER

- Step 1.** Turn the gas cylinder valve on in an anti-clockwise direction for one full turn.
- Step 2.** Using long BBQ matches or gas lighter, position close to the edge of the burner to be ignited, slowly turn the gas control in an anti-clockwise direction approximately $\frac{1}{4}$ of a turn.
- Step 3.** If the burner does not ignite, turn the gas control in the clockwise direction to the "OFF" position and allow the residual gas to disperse before attempting to reignite.



Note: Locate the gas cylinder away from your cooker to ensure it is not subjected to radiant heat.



TURNING THE APPLIANCE OFF

If the appliance is no longer to be used and to reduce the risk of blocked gas jets caused by excess gas being left in the hose, all remaining gas must be expelled from the hose assembly.

- Step 1.** With the flame still operating, turn the valve on the gas cylinder in the clockwise direction until it is off. Allow the flame to burn down then extinguish once all remaining gas in the hose has been used.
- Step 2.** Turn the gas controls on the appliance clockwise to the “OFF” position.

CARE INSTRUCTIONS

Using warm soapy water with a mild detergent wipe down all surfaces and areas of the appliance, taking care not to allow water to enter the burner outlets or aeration holes located in the burner tube.

DO NOT submerge the appliance in a sink or bowl.

DO NOT use abrasive cleaners or bleach.

MAINTENANCE AND SERVICE

During operation if it is noted that the burner flame is unstable, is changing colour from blue to yellow or has a distinct smell it is important that you take the appliance to your local authorised gas appliance repairer for inspection.

Periodically check the gas control is tight and has no leaks, follow the testing for leaks procedure. Check the gas hose and regulator for any signs of wear, cuts or fraying, if identified replace immediately with a Gas Certified replacement hose and/ or regulator.

For further information or assistance please contact customer service.

TECHNICAL DETAILS

SPECIFICATIONS	
Part No.	SGB04
Certification	AGA 8280G
Size	360L x 560W x 325Hmm
Weight	5.0kg
Output	85,300 BTU

GAS JET	
Burner	1.02mm

CONSUMPTION	
Inlet Pressure	Cylinder Pressure
Gas Type	ULPG
Consumption	1786g/Hr
	90mj/Hr

A selection of spare parts and components are available for your appliance to ensure years of operation.

Australia: Call 1300 555 197 or Email service@companionbrands.com.au

New Zealand: Gladiator Sports - www.roman.co.nz



Distributed by
Companion Brands
Bundoora Victoria 3083
www.companionbrands.com.au