

PITCHING INSTRUCTIONS - POCKET ROCKET

1. Ensure guy ropes are pegged out at all times during use
2. Never pack your tent away wet. If you must take your tent down when wet, ensure that you dry your tent completely as soon as possible to prevent mildew forming.
3. If mildew does form on your tent wash off with warm water and a soft brush to prevent further growth. Do not use detergents.
4. Do not use an open flame inside your tent. The fabric has been treated with a fire retardant but is in no way fire proof
5. Clean all pegs and poles before storing
6. This tent is not designed to withstand storm conditions. During strong winds, it is recommended that the tent be taken down
7. Do not leave your tent pitched unnecessarily for extended periods of time. UV light damages the fly fabric and will shorten the life of your tent

Flow Imports Ltd General Warranty

Subject to the exclusions and limitations set out below, Flow Imports Ltd will repair or replace (at its choice) merchandise supplied by Flow Imports Ltd (Goods) which fail due to faulty materials and manufacture during the warranty period.

The following exclusions and limitations apply to the Warranty:

The Warranty does not apply except to an original purchaser who purchased Goods new from a retail outlet.

The Warranty does not apply if:

- (a) a different product specific warranty is provided by Flow Imports Ltd; or
- (b) the Goods are not made by Flow Imports Ltd and an express warranty is provided by the maker of the Goods

The Warranty does not apply if the Goods have been used other than for reasonable personal camping use. Use in a commercial context (e.g. for rental or use by a commercial organization in its business operations) or continuous use in a domestic context are expressly excluded.

Damage due to reasonable wear and tear, accident, acts of God, negligence (other than by Flow Imports Ltd), failure by the purchaser to ensure instructions for use and care are observed, deterioration due to abnormal exposure to the elements, insect or mildew attack, or any other cause reasonably beyond the control of Flow Imports Ltd are all excluded.

Goods must be returned by the purchaser to the outlet from where they were purchased within the Warranty period, in a clean state with proof of purchase.

All transport cost and any other indirect costs are excluded from the Warranty. Flow imports Ltd reserves the right to make a reasonable charge for repairs which it determines are not within the scope of the Warranty.

The Warranty does not limit, modify or exclude any rights under any law if to do so would contravene that law or make any part of this Warranty invalid. However, Flow Imports:

- (a) Excludes (to the extent permitted by applicable law) all conditions and warranties that might otherwise be implied; and
- (b) Limits its liability for breach of any such condition or warranty that it cannot exclude together with its liability under Warranty, to repairing or replacing the Goods or paying the cost of having the Goods repaired or replace (at Flow Imports' option).

For a detailed description of all the features and specifications of this product please visit our website.

WWW.ZEMPIRECAMPING.COM

Tested in New Zealand. Made with care in China


zempire
BY FREEDOM CAMPING



POCKET ROCKET
SHELTER SERIES


INSTRUCTIONS

zempire
BY FREEDOM CAMPING




1. Assemble the 4 pole sections. Ensure that the poles are inserted fully into the steel connectors.


2. Insert the end of the pole without the steel connector into the 4 way connector attached to the top of the tent. Repeat with all 4 poles





3. Tension the poles and insert the pins located at the base of the tent into the ends.




4. Connect the C Clips sewn into the tent around the corresponding pole. You may need to lay tent down to reach the top clips.



5. Place the vent cover over the top of the tent and hook on the corners to the loops sewn along each pole line. once again, it may be easier to lay the tent on its side to do this step.



6. Ensure the door is closed. Peg out all peg points around the base of the tent. Try to make the poles evenly spaced apart.



7. It is recommended that guy ropes are pegged out at all times. Try to have guy ropes at a 45° angle to the ground.

This tent design is under copyright protection by Flow imports Ltd. The Zempire Logo and related campfire mark are registered trademarks of Flow imports Ltd, New Zealand. Any reproduction of this manual is prohibited without prior consent by Flow imports Ltd.