



Ozpig
Spark Arrestor
\$19.00





Details

The Spark Arrestor is an important part of your Ozpig, as it prevents embers from escaping. If yours is lost or damaged, you'll need a Spare Spark Arrestor quick-smart. This spare part fits on top of the chimney of your fully assembled existing Ozpig cooker to contain the embers. Compatible with separately available Ozpig cooker Genuine Ozpig spare part

Specifications

Snowys Code:	140406
Supplier Code:	SPARK ARRESTOR
Packed Dimensions:	6L x 6W x 1.1H cm
Material:	Alloy
Weight:	0.018 Kg
Warranty:	1 Year

Have a question about this product?

 1300 914 007  service@snowys.com.au  Snowys Outdoors  Snowys Outdoors

Changed your mind?

For all information on how to return an item, visit www.snowys.com.au/returns